

ResTape Teflon® Tape

- For threaded connections in a wide range of plumbing materials.
- Each roll is 1/2" x 260".
- Maximum temperature: 260°C.

Description	Uses	qty.	cat.#
ResTape Green PTFE	oxygen service*	ea.	22485
ResTape Yellow PTFE	general gas service**	ea.	22486
ResTape Grey PTFE	stainless steel fittings***	ea.	22487



Ridgid® Heavy-Duty Tubing Cutter

- Specifically designed to cut 3/16-1 1/8" stainless steel tubing.
- Large knob and 6 individual bearings for more control with less turning.
- Convenient fold-away reamer.

Description	qty.	cat.#
Ridgid® Heavy-Duty Tubing Cutter	ea.	22621



Strap Wrench

- Securely grip large, hard to turn items.
- Safely grip sample cylinders without damage when installing valves.
- Large capacity: 8" diameter cylinder.

Description	qty.	cat.#
Strap Wrench	ea.	22625



Heavy-Duty Tube Bender

- Allows precise bending of 1/4" tubing.
- Patented swivel handle can be repositioned easily, allowing easy fabrication of bends up to 180°.
- Does not score or flatten tubing.
- Calibrated to show angle of bend.

Description	qty.	cat.#
Heavy-Duty Tube Bender	ea.	22626



Flexible Inspection Light

- Inspect inside surfaces of sample cylinders or other chambers.
- 14" reach.
- 100,000-hour LED life.

Description	qty.	cat.#
Flexible Inspection Light	ea.	22627



Swaging Tool

- Preswage compression fittings for easy installation.
- Ideal for installations in tight areas.
- For Swagelok® fittings only.

Description	qty.	cat.#
Swaging Tool	ea.	22622



Tee Wrench

- Hold 1/4" or 6mm tee or cross fittings secure in multiple orientations during installation.
- Fits easily in tool box, pouch, or belt.
- Cushioned vinyl grip with generous gripping area.
- For Swagelok® fittings only.

Description	qty.	cat.#
Tee Wrench	ea.	22623



Gap Inspection Gauge

- Confirm that fittings are sufficiently tightened.
- For use with 1/4", 3/8", 1/2" Swagelok® fittings.
- For Swagelok® fittings in new installations only.

Description	qty.	cat.#
Gap Inspection Gauge	ea.	22624



*Compatible with gaseous or liquid oxygen, and with many other gases and liquids.

**Compatible with a broad range of gases and liquids.

***Anti-galling. Also compatible with many other metals and polymers.

RESTEK PERFORMANCE COATINGS